
CABINET CISTERN

Sensor-flush with glass front



INSTALLATION INSTRUCTIONS


Content


Item list	2
Technical specifications	4
Technical drawing, inlet system &drainage system	5
Installation·····	6
Maintenance & daily care · · · · · · · · · · · · · · · · · · ·	14
Warranty	20


Item List


Item List	Names	Specification	Quantity	Item List	Names	Specifications	Quantity
	rubber seal	ø110	1		expansion nut	SX10 Ø6-8	2
	straight flush pipe		1		screw	ST6.8*67	2
0	flush pipe		1	©	washer	ø22*2.0	2
	eccentric pipe		1		M12 bolt		2
0	rubber seal		1	0	decorative cap		2
	transparent air hose	transparent L:350mm	1	©	M12 nut		2
	blue air hose	blue L:300mm	1	0	big washer	φ32.5*2.5	2
	transparent air hose	transparent L:650mm	1	©	rubber sleeve		2
\	flush pipe		1	0	decorative cap base		2
•	rubber seal on above pipe	ø60	1		steel expansion bolts		2
•	expansion nut	8*40	2	©	washer	ø11*1.2	2
•	screw	ST4.8*45	2	0	toilet mat		1


Item list



































Technical Specitication

Name	Automatic Infrared cabinet cistern for wall-hung WC				
Model	SP-S18				
Technical Specitication	rated voltage	220V AC, 50HZ			
	ambient temperature	3~40°C			
	water supply pressure	0. 07~0. 75MPa			
	water supply temperature	4~35°C			
	waterproof rating	IPX4			
	dimension	1003.5mm X 483mm X 108mm			


Technical drawing, inlet system & drainage system suggestion









Cistern installation




Insert the drainage pipe into the drainage hole on the wall.




3







As indicated by the arrow, mark 4 spots on the wall and 2 spots on the ground accordingly.




Then move off cistern first.




Drill the holes to the marked spots(Note the depth of the drill must be larger than the length of expansion nut, the diameter shown as the picture) and press the corresponding expansion nut into the hole.




Lean the whole frame into the right position of the wall.




Lock the corresponding size of the screws into the expansion nut in the wall and steel expansion bolt on the floor.




Buckle the braided tube onto the hanger again, and connect the tube to the angle valve on the wall.





Open the stop valve on the hose to see whether it is in good condition.




 $\label{eq:Mark:All batteries should be AAA batteries}, \ \ \text{and please do not mix old and new batteries when using.}$













Install the glass onto the aluminum frame and push downward the glass support buckle until the buckles lock with pendant the aluminum frame.











Draw line on the straight flush pipe and drain pipe.




Cut the flush pipe and drainage pipe.





Apply chamfer on the mouth of the flush pipe and drain pipe.

Apply silicone oil.




Screw the bolts into the cistern frame







Install toilet mat.




Install the flush pipe onto the cistern,




Install the flush pipe onto the toilet.



Install toilet.




Cut off extra part of the toilet mat.




Sensor area: wave your hand within around 50 mm from the top cover to test the function of half & full flush.

Maintenance & daily care


1.1 Inlet valve removal




Remove the top cover and unplug the mating parts.



Turn off the stop valve on the flexible hose.




Disconnect hose and the valve.





Take off the inlet valve upwards.


1.2 Inlet valve adjustment & clean



Adjust the float upwards to increase the inlet volume; or downwards to reduce the volume.










Wash this removed part.

1.3 Inlet valve installation









Buckles on the cistern hunger.


Lift upwards the flush valve after opening the buckles on the cistern hunger.




2.2 Flush valve adjustment & clean




Adjust the float upwards to reduce the flush volume; or downwards to increase the volume.




2.3 Flush valve installation.




Install the flush valve downwards into the cistern body(Mark: make sure the flush valve bottom is aligned with flush valve base. And please make sure flush valve is installed in the shown direction during installation.





Re-install the lever.



Re-install the top glass cover.